

INSTRUCTION MANUAL

VACUUM CLEANER



JLL1002 Series

This appliance is for household use only

Safety instructions

! Read all the safety instructions before you use your vacuum cleaner

Power source

- You should only plug your vacuum cleaner into a 220-230V AC 50/60Hz supply

Using your vacuum

- For safety reasons you should not vacuum wet surfaces, pick up wet objects or use in wet conditions.
- Do not use the vacuum cleaner to pick-up burning objects as this is a fire risk!
- Do not pick up hot objects such as coal and ashes.
- Do not use the vacuum cleaner to pick-up large objects that are likely to cause damage.
- Do not run over the mains cable with your vacuum cleaner. Do not use with damaged cord.
- Use only for domestic use. Industrial or commercial use invalidates the warranty.
- Most new carpets have a breaking in period in which only light vacuuming is recommended.
- Do not let children use the vacuum. Keep hair, loose clothing, fingers, feet and body parts away from openings or moving parts.
- Do not use without dust bags or filters in place.

Transporting your vacuum

- To move your vacuum cleaner from room to room, unplug the unit and carry using the carry handle.
- Never pull the vacuum cleaner by its cord or the flexible hose when moving.

Servicing and maintenance

- Ensure you replace the filters when necessary.
- Always empty the bag when indicated on the vacuum cleaner.
- The plug of the power cord must be removed from the wall socket before changing the bag, cleaning the appliance or undertaking any maintenance operations.
- If the power cord becomes damaged, do not use the vacuum cleaner, it must be replaced by an authorised service agent.

Specification

Model Number:	JLL1002 series
Filtration:	5 level filtration
Features:	floor brush 2-in-1 brush extension tube suction control on the hose handle

Parts identification



1.Floor head.

2.Extension tube.

3.Suction control.

4.Hose handle.

5.flexible hose.

6.Filter outlet.

7.Top carry handle.

8.Cable rewind button

9.Power button.

10.Bag full indicator.

11.Dust bag compartment.

12.Dust bag compartment catch.

13.Carry handle.

Assembly

- Remove your vacuum cleaner carefully from the box. You may wish to store the packaging for future use.


Mains power

- Your vacuum cleaner is equipped with a cord power and plug.
- Plug your power cord into the main socket. Ensure the voltage is compatible before switching on your vacuum.
- When not in use, unplug your vacuum from the mains power.

Assembly




- Place the Hose connector into the hose inlet socket as shown above.
- To release the hose connector press the button on the side of the connector and pull out of the hose inlet socket.



- Slide the upper handle into the extension tube (if required).



- Slide the upper tube into the bottom tube



- Slide the extension tube into the required attachment.

Using the vacuum cleaner

Switch on



- Press the On/Off switch to turn the cleaner on.


Rewinding the cable



Using the VC

- The floor head is generally used for daily cleaning of carpets and hard floors.
- The crevice tool can be used for slipping down the side of chairs and sofas, reaching into corners along baseboards etc.
- The upholstery tool can be used for vacuuming chairs, curtains and more delicate areas.
- Connect the required tool by pushing and twisting gently onto the end of the extension tubes.
- Pull the power cord gently to the required length, the maximum length is signified by the yellow and red marking on the power cord.
Do not attempt to pull past the red marker.
- Ensure that your power supply is 220-230V AC 50/60Hz then plug the cord into the outlet.

Hold the cable in one hand, and press the cable rewind button with your foot, feeding the cable back slowly.



WARNING

IMPORTANT:
DO NOT USE THIS CLEANER STANDING ON END. THIS WILL CAUSE OVERHEATING AND MAY DAMAGE THE CLEANER OR FLOOR COVERINGS.

Maintenance

DUST BAG

- The bag full indicator will automatically change to red when the dust bag is full or when the tube is blocked. The bag should be changed and/or the blockage should be removed from the hose or tubes to prevent the vacuum cleaner from overheating and causing damage.

To change the dust bag



- Turn the top of the dust bag compartment catch and lift the dust bag compartment cover until it clicks in the upright position.
- Pull out the dust bag.



Replacing the bag

- Slide the bag into the bag holder.
- Close the dust cover lid.

FILTER CLEANING

Filter 1

- The filter should be removed and rinsed twice a year or whenever it is visibly clogged.
- Always operate the unit with the filter installed or damage may occur to the unit.
- Remove the dust bag as shown on the left, the filter is shown in the diagram below.



- Remove filter.
- Hand wash in cool soapy water.
- Rinse thoroughly under running water to remove all particles and soap.
- Allow to dry naturally.
- Replace filter when dry, operating with a damp filter will damage the motor and void the warranty.

Filter 2

- The second filter is located at the rear of the unit.
- To clean this filter unclip the grille as shown in the diagram and shake the filter to clear any dust which may have accumulated. It's washable in water as well.



- Replace the grille.

Do not machine wash the filter and do not attempt to dry using any kind of heated appliance.

Store & stow away system



Store system



Stow away system



2-in-1 nozzle store compartment

This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.

If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard."



Any electronic equipment or electrical defect which you want to dispose, shall be deposited in an appropriate recycling center: Consult your dealer.

